



Stickers installation guide

R /7 series

Always: get surface extremely clean and make sure it's nicely warm (20C/68F or up)
Then apply sticker from the center and press outwards to its ends.



paint
colour
code
as seen on a 1980 R100T



BOSCH
coils
after 1980 pictured



E1
homologation
code



Use DOT3
reminder
after 1983 Dot4

Colour
Inspektion
Achtung
Tyres
Service memo
on a 1983 R80ST



TYP RS1
only for the
'77 R100RS

Use Original
Parts
US version pictured



Reproduction stickers & decals

For classic BMW airheads 1960s to early 1990s

[instagram.com/heritagestickers](https://www.instagram.com/heritagestickers)

[facebook.com/heritagestickers](https://www.facebook.com/heritagestickers)

www.heritagestickers.eu

heritagestickers@gmail.com

